

CTFPND-2 Handy Pairing How-To

Choose the symbol which is marked on the picture with your touchscreen to setup a pin code.



You can choose the pin code freely. We picked '0000' as the default pin.



After confirming the pin code with 'OK' you can return to the Bluetooth main menu.

Choose the icon which is marked in below picture via touchscreen.



The following screen will appear:



Please activate your bluetooth function on your mobile phone now. The device must be set on visible for all applications. Now search for new devices via your mobile phone. A device called 'Navi-BT' will appear now.



After you choose this connection, you will be prompted to enter the pin code you previously set up. After successful connection of the two devices the following screen will appear:



14.02.2009, Timo Decristan